



Vista frontale - Front view




Normalmente preimpostato per fondo scala 1999A - Factory full scale preset at 1999A


IMPOSTAZIONE FONDO SCALA AMPERE - AMPERE FULL SCALE SETTING

0,200A	2,00A	20,0A	200A	2000A
0,250A	2,50A	25,0A	250A	2500A
0,300A	3,00A	30,0A	300A	3000A
0,400A	4,00A	40,0A	400A	4000A
0,500A	5,00A	50,0A	500A	5000A
0,600A	6,00A	60,0A	600A	6000A
0,750A	7,50A	75,0A	750A	7500A
0,800A	8,00A	80,0A	800A	8000A
1,000A	10,0A	100,0A	1000A	10000A
1,200A	12,00A	120,0A	1200A	12000A
1,250A	12,50A	125,0A	1250A	12500A
1,500A	15,00A	150,0A	1500A	15000A
1,600A	16,00A	160,0A	1600A	16000A
1,999A	19,99A	199,9A	1999A	19990A

Schema inserzione - Wiring diagram



Impostazione dip-switch frontali per visualizzazione 600V c.a.
600V AC full scale front dip-switch setting.



Dimensioni ingombro - Overall dimensions

